

Lymphocyte Absolute CD4 and CD8

Order Name: **T HELP/CYTOTOX**

Test Number: 5603200

Revision Date: 05/24/2023

TEST NAME	METHODOLOGY	LOINC CODE
Lymphocyte Absolute CD4 and CD8	Flow cytometry	

SPECIMEN REQUIREMENTS

Specimen	Specimen Volume (min)	Specimen Type	Specimen Container	Transport Environment
Preferred	5 mL each (3 mL each)	Whole Blood	EDTA (Lavender) and ACD Sol A/B (Yellow Top)	Room Temperature
Instructions	Collect Whole blood in Both ACD Solution A or B (Yellow Top) and EDTA (Lavender Top) . Keep whole blood, do not centrifuge or refrigerate. Deliver to the laboratory ASAP - Same Day as Collection! Stability: Room Temperature, Yellow-top (ACD-A) or (ACD-B) tube: 2 days Lavender-top (EDTA) tube: 1 day Collect Monday through Thursday only. Specimens must be received at Labcorp Oklahoma Inc. by Thursday afternoon or collect on Monday.			

GENERAL INFORMATION

Testing Schedule	Testing schedule may vary
Expected TAT	3-5 Days
Clinical Use	Immunophenotype of T lymphocytes.
Performing Labcorp Test Code	096925
Notes	This panel is also known as: T Helper and Suppressor Cells (CD4/CD8)
CPT Code(s)	86359, 86360
Lab Section	Reference Lab